

Q40

+

Q60

MAINBOARD

USER'S MANUAL

Preliminary version 02/2001

Chapter 1: Overview

Key Features

The Q40 mainboard is a 40 MHz high-performance Sinclair QL replacement mainboard based on the Motorola MC68040 microprocessor with mathematical coprocessor and memory management unit. It features 32 bit highcolor / highresolution graphics while maintaining QL hardware compatibility.

Like the original QL mainboard the Q40 is a complete solution including graphics, peripherals and sound. It fits directly into an industry standard case. It doesn't need any parts from an existing QL and no CPU card or keyboard interface.

The Q60 mainboard is a top-speed system, based on the Motorola MC68060 superscalar microprocessor architecture. It includes all the features of the Q40, and adds even faster processing speed of up to 160 MIPS at 80 MHz.

RAM

4 MB up to 32 MB of DRAM. EDO or FPM memory modules can be used. Two 72 pin PS2-SIMM sockets simplify upgrading. No jumpers are required for size detection.

On the Q60 only EDO modules are supported, no FPM. Support for up to 128 MB of DRAM can be realized by a special hardware option.

ROM

256 KB, data bus 32 bit wide by using two 16 bit devices. The mainboard supports up to 1 MB ROM capacity.

Graphics

On-board highspeed graphics chipset and 32 bit dual-ported video RAM. 72 Hz vertical refresh rate, non-interlaced in all modes, dual scan capability for the low resolutions. Supports multisync monitors with at least 38 kHz horizontal frequency. Output connector options are 15 pin HD (VGA) or 9 pin SubD (PS/2).

Video modes

- QL mode 8 256x256 pixel, 8 colors
- QL mode 4 512x256 pixel, 4 colors
- High color mode 512x256 pixel, 64K colors
- High color mode 1024x512 pixel, 64K colors

Keyboard Interface

Port for MF-102 keyboards. 5 pin DIN connector.

Sound

Stereo digital-analog converters, 10kHz or 20kHz sample rate selectable. Line and headphone outputs.

Clock and Nonvolatile RAM

- Battery buffered real time clock
- 2 KB nonvolatile static RAM

Disk Interface

- Enhanced IDE Controller for 2 Harddisks (16 bit wide data transfer) or other IDE drives like CDROM
- Floppy Controller for 2 HD floppies

Ports

- 2 serial ports with 115200 Baud
- 1 parallel port
- 1 joystick port

Disk interface and ports are on a small IDE / Multi IO card that belongs to the mainboard.

Extension Slot

The mainboard has two extension slots, one of them is occupied by the IDE / Multi IO card. There are 16 data lines and 20 address lines, all signals are buffered and have a well defined timing. Signals and pinout also allow many ISA cards to be used in the slot.

Board size

The Q40 and Q60 mainboards have a size of 8.2 x 6.3 inch and can be directly mounted in industry standard cases for the AT form factor. (Mounting in ATX case should also be possible, but may require special plate for connectors.)

Power Supply

An industry standard power supply can be directly plugged into the Q40 or Q60. A power connector known from harddisks and 5.25" Floppys is used.

Q40 / Q60 System

A complete Q40 or Q60 system can be a Q40 / Q60 Mainboard in combination with IDE Harddisk(s), CD-ROM or CD-RW drive and HD Floppy(s) mounted in an industry standard case with power supply, and a MF-102 keyboard. Additional hardware extensions like Ethernet are supported by the extension slot. Please note that not all operating systems may support the possible hardware options.

QL Compatibility

QL screen modes 4 and 8 are directly hardware compatible, ignoring mode 8 flashing. The 50 Hz frame interrupt is available. Memory map and interrupt handling are similar, but ports have changed. Microdrives and the slow QL network are no longer supported.

Unpacking & Handling instructions

The Q40 or Q60 mainboard package should contain the following items:

1. The mainboard with CPU already installed
2. This User's Manual
3. Video cable with 15 pin HD or 9 pin SubD connector
4. IDE/IO card, second serial port and joystick cables/bracket, floppy cable, harddisk cable
5. PS/2-SIMM Memory module(s) (optional)
6. Sound cables (optional)

The Q40 or Q60 mainboard can be damaged by static electricity. Do not remove the mainboard from its packing until you are ready to install it. Touch the systems chassis before handling the mainboard or any component. Shipping may have loosened integrated circuits from their sockets. If any circuit appears loose, press carefully to seat it firmly in its socket.

Chapter 2: Hardware Configuration

Mainboard

Please make sure that the power supply is turned off before making any connections to the board. Before you fix the mainboard in the system chassis, it is recommended that you first the install memory modules and attach the 5 / 12V power supply cable.

When attaching any system components to the mainboard via the mainboard connectors, please pay attention to the correct direction. In the figure **Mainbord Component Locations** the pins number 1 of the connectors **Line Out**, **Speaker Out**, **LED**, **ROM selector** and **Video Out** are on the upper side. The extension slots, DRAM sockets and the keyboard connector are constructed so that their counterparts only fit if they are turned into the correct direction.




Figure: Mainbord Component Locations

Extension Slot

The IDE/IO card must be installed in one of the extension slots. Both extension slots are identical, so it doesn't matter into which of the two slots a card is installed. When pressing a card into an extension slot, hold the mainboard and take care not to bend it.

Line Out

Line Output for stereo systems or active loudspeaker boxes. The line impedance about 1 k Ω .

Pin	Description
1	Left channel
2	Ground
3	Right channel

Speaker Out

Output for headphones or other low-power speakers with an impedance of 32 Ω or more. (Smaller impedances will not damage the mainboard, but may not sound loud enough.)

Pin	Description
1	Left channel
2	Ground
3	Right channel
4	Ground

Reset

Connector for a manual reset switch.

Setting	Description
Open	Normal mode
Short	Hardware Reset

LED

Programmable LED Output.

Pin	Description
1	Cathode (Minus)
2	Anode (Plus)

ROM Selector

Selection of ROM function. The settings „2-3“ and „Open“ allow to divide the ROM into 128 KB parts, and a jumper or switch selects which part is accessed.

Setting	Description
1-2	Normal Operation with 256 KB ROM or more. (Default) Only use a jumper for this connection! It is not allowed to attach a cable between pins 1 and 2 of the ROM selector, because high-frequency signals are routed via this connection.
2-3	Use only lower 128 KB of the physical ROM device. A cable can be used to attach a switch between pins 2 and 3.
Open	Use only upper 128 KB of the physical ROM device and let them appear at the beginning of the logical ROM address space(s).

Video Out

Analog Video Output for multisync monitors with at least 38 kHz horizontal frequency. A short cable is provided with the mainboard, which leads the signals to a 15 pin HD or 9 pin SubD connector that can be mounted at the case.

Pin	Description	Pin	Description
1	Red	2	Ground
3	Green	4	Ground
5	Blue	6	Ground
7	Horizontal Sync	8	Ground
9	Vertical Sync	10	No connection

Please adjust the horizontal picture size and position on your monitor to avoid distortion at the border of the display. Problems like flickering or wrong colors can be caused by too slow monitor timings or extension cords.

Keyboard

Five-pin female DIN connector for MF-II keyboards (IBM-PC/AT keyboards).

Power Supply

Four-pin male connector for industry standard drive power supplies with +5V and +12V. To avoid bending the mainboard, press in the supply connector before fixing the mainboard in the case.

DRAM sockets

The mainboard lets you add up to 32 MB of DRAM via two memory banks on the mainboard. Each bank has a 72-pin PS/2-SIMM socket. The mainboard supports the following memory configurations:

Bank 0	Bank 1	Total memory
4 MB (single-sided)	None	4 MB
16 MB (single-sided)	None	16 MB
16 MB (single-sided)	4 MB (single-sided)	20 MB
16 MB (single-sided)	16 MB (single-sided)	32 MB
32 MB (double-sided)	none	32 MB

The Q40 mainboard can use both DRAM types: Fast Page Mode (FPM) or Extended Data Out (EDO). All PS/2 SIMM modules must be faster than 70 ns access time. Use only memory modules with decoupling capacitors on board!

The Q60 mainboard supports only EDO modules. All PS/2 SIMM modules must be 60 ns access time or faster for the Q60. Use only memory modules with decoupling capacitors on board!

Some mainboards contain a special hardware option for up to 128 MB. If your mainboard has been upgraded with this special option, the following memory configurations will be added:

Bank 0	Bank 1	Total memory
64 MB (single-sided)	None	64 MB
64 MB (single-sided)	16 MB (single-sided)	80 MB
64 MB (single-sided)	64 MB (single-sided)	128 MB

Please note that support for more than 32 MB of RAM may not be available under all operating systems.

ROM sockets

The mainboard uses two 16 data bit wide ROM or EPROM devices for 32 bit wide access. One device is for the high data words and one for the low data words. The (EP)ROM device for the High Words must be seated into the socket near to the DRAM. (EP)ROMs have a direction mark, which must point to the same direction as shown in the figure **Mainbord Component Locations**.

IDE/IO Card

Please read the manual of the IDE/IO card for details. Currently most combinations of operating systems and IO cards on the Q40 or Q60 require that the Printer Mode ist set to SPP and the IRQ7 jumper for the printer interrupt is removed.

Floppy

Up to two high density floppy disk drives can be connected.

IDE harddisks

The IDE/IO card supports 2 (optional 4) IDE harddisks or ATAPI devices. Please notice that special driver software might be required to support ATAPI devices like CDROM drives. Make shure that your device is supported by the software you use on the Q40 / Q60.

IDE harddisk used with the Q40 / Q60 should support PIO mode 2 or faster.

Serial, Parallel, Joystick

The IDE/IO card contains the serial port SER1 on a male 9 pin SubD connector and the parallel port PAR1 on a female 25 pin SubD connector.

On a bracket that comes together with the IDE/IO card, you can find the serial port SER2 on a male 25 pin SubD connector and an analog joystick input on a female 15 pin SubD connector. The bracket must be connected to the card.

Chapter 3: Memory Map

On the next page you can see the QL and the Q40/Q60 memory map as an overview about the physical hardware locations.

A detailed description about the Q40 and Q60 hardware for programming operating systems or physical device drivers is also available. This description is not included in this User's Manual, because it is not helpful for normal operation and incorrect use can cause system crashes or data losses.

Address(hex)	QL	Q40
0000 0000 0000 BFFF	Internal ROM 48K	ROM 0 96K (Normal Mode: Read from ROM, Write to RAM LOWRAM Mode: Read from RAM, No Write)
0000 C000 0000 FFFF	External ROM 16K	
0001 0000 0001 7FFF	External I/O 32K	
0001 8000 0001 BFFF	Internal I/O 16K	
0001 C000 0001 FFFF	External I/O 16K	RAM 32K
0002 0000 0002 7FFF	Screen 0 32K	
0002 8000 0003 FFFF	RAM 96K	RAM up to 32608K (4,16,20,32MB)
0004 0000 000B FFFF	Expansion RAM 512K	
000C 0000 000F FFFF	Peripheral ROMs 16 x 16K	
0010 0000 01FF FFFF		
		Up to 130432K as special option only (64,80,128MB)
FE00 0000 FE03 FFFF		ROM 1 256K lower 96K are ROM 0
FE80 0000 FE8F FFFF		Screen 1 1024K 32K at \$FE820000 are mirrored at Screen 0
FF00 0000 FF00 0034		Master Chip (Keyboard, Interrupts, Video Mode, LED, Extension Slot Reset)
FF00 8000 FF00 8004		Audio-DACs
FF01 0000 FF01 8000		Address Decoder Chip (ROM Mode Selection)
FF02 0000 FF02 1FFC		Nonvolatile RAM 2K Realtime Clock
FF40 0000 FF7F FFFF		Extension Slot IO 1024K
FF80 0000 FFBF FFFF		Extension Slot MEM 1024K

All specifications are subject to change without notice. No responsibility is assumed for inaccuracies or errors.